


NOVUX™ Fiber Optic System NVX- CR-MC-RD/FT-NN: Cable retention - Jacket (Mclip)

1 Cable diameter range


	mm	inches
Round cable	4 - 6,2	0.16 - 0.24
Flat cable	8 x 4,5	0.32 x 0.18

2 Tools




- Cable stripping and cleaning tools
- Scissors (to cut aramid yarn)

3 Kit contents




N°	Description	Qty
1	Carrier	1
2	Metal clip for round or flat cable	1

4 Prepare cable



N.º	Description	Preparation
1	Jacket	<p>! Attention: The distance of the jacket that should be removed is depending on the closure where the cable retention is installed. Distances below are valid for cable stubs:</p> <ul style="list-style-type: none"> • CC 100: 130 ±5 cm / 51 ±2 Inches • CC 150: 135 ±2,5 cm / 53 ±1 Inch • CC 200: 135 ±2,5 cm / 53 ±1 Inch • SRC 100: 90 ±5 cm / 35 ±2 Inches • SRC 50: 130 ±5 cm / 51 ±2 Inches
2	Dual jacket (if present)	Make the dual jacket as small as possible; keep a maximum length of 1,2 cm / 0.47 Inches. Remove the aramid yarn inside this second jacket.
3	Aramid yarn/ Rigid strength member	Aramid yarn and rigid strength member are not used within this kit.
4	Subunits	<p>Clean the subunits, remove all grease. The subunit tube should be removed to access the fiber.</p> <p>! Attention: Stripping point of the subunit is provided in the closure installation instructions.</p>


5 Install the cable on the carrier




- 1 Align the sheath opening with the rib on the carrier.
- 2 Mount the clip on the cable - carrier assembly. The two slots of the metal clip should be positioned in the two tabs of the carrier, then turn the clip towards the cable.
- 3 Push until the two snap hooks snap into the slots of the metal clip. Pliers are allowed to close the clip properly.

6 Install carrier


To secure the cable to the organizer, the three hooks on the rear side of the carrier should slide into the 3 slots on the interface plate on the organizer. The top left slot has a locking lip to keep the cable - carrier assembly in place.





- 1 Slide the carrier with the cable secured into the slots of the organizer. Push the locking lip in the first slot backwards.
- 2 Slide the carrier downwards.
- 3 The locking lip returns into its original position and the carrier is correctly seated. A clicking sound is observed.

7 Remove carrier



- 1 Position a fiber guidance pen in the little cavity in the locking lip of the first slot and push the locking lip backwards. When the lock is released, lift the carrier up.
- 2 Move the carrier with cable attached forward.