COMMSCOPE[®]

Installation Instructions

TC-1592-IP Rev. A, February 2024

NOVUX™ Fiber Optic System NVX-UMB-NN-SM-R01: Mounting Bracket

Applicable for SRC10

1 Kit contents



N°	Description	Qty
1	Mounting bracket	2

2

Install the mounting bracket



- 1 Position the SRC10 closure in front of the mounting bracket tab.
- 2 Install the SRC10 closure as shown in the pictures above until it snaps onto the mounting bracket.
- 3 Secure the SRC10 closure and cables with cable ties.
- Bote: Cable ties are not included.

All trademarks identified by [®] are registered trademarks in the US and may be registered in other countries. All third party product names, trademarks are property of their respective owners. This product may be covered by one or more U.S. patents or their foreign equivalents. For patents, see www.cs-pat.com. This document is not intended to modify or supplement any specifications or warranties relating to CommScope products or services. Visit our website or contact your local CommScope[®] representative for more information. www.commscope.com. For technical assistance, customer service, or to report any missing/damaged parts, visit us at: http://www.commscope.com/SupportCenter.



Note: Mounting hardware (screws) not included.

4 Pole mounting



Note: Mounting hardware (straps) are not included.